



Technical Service Bulletin

Technical Service Bulletin: tsb100157

Released Date: 04-Apr-2002

New Cylinder Head Gasket

New Cylinder Head Gasket

Warranty Statement

The information in this document has no effect on present warranty coverage or repair practices, nor does it authorize TRP or Campaign actions.

Contents

This Technical Service Bulletin updates a change made to the QSK45 and QSK60 series cylinder head gasket.

The seven bolt hole grommets in the cylinder head gasket have an increased thickness to improve sealing when using high-pressure steam to clean the engine exterior. This cylinder head gasket also incorporates the previous change in material used to make the four coolant grommets, which provide improved resistance to thermal degradation in elevated temperature applications.

Engine serial number first is 33150786, built October 11, 2001.

Cylinder Head Gaskets

Part Number	Gasket Status
4066243	Old
4080532	New

Note : This is a product improvement and is **not** subject to campaign.

Last Modified: 04-Apr-2002